



Care and use instructions

CAUTION

- Not intended for use with hot liquids.

USAGE RECOMMENDATIONS

- To use, insert your ingredients into the bottle with the shaker ball and shake according to drink manufacturer instructions. Make sure the lid is screwed on tightly and the flap is snapped all the way down before shaking.
- DO NOT continue to use product if damaged.



Pour in the powder



Shake



Ready to drink


RECOMMENDED FOR

- Protein powders, nutrition supplements, meal replacements and any other powdered beverages.

CLEANING INSTRUCTIONS

- Wash thoroughly before first use.
- Rinse immediately after each use with warm water.
- Lid, plastic body and the ball are top-rack dishwasher safe.

contigo®



- If washing by hand, wash all the parts with warm water and mild detergent. Rinse all parts thoroughly before drying.
- ALWAYS STORE BOTTLE WITH LID REMOVED to allow parts to dry completely.

